

DURACELL®

Instant USB CHARGER



Using the Instant USB Charger

CAUTION: The lithium-ion rechargeable battery used in this charging device may present a risk of fire or chemical burn if mistreated. Do not disassemble, expose to heat above 100° C (212°F), or incinerate. Misusing or incorrectly connecting the charging device may cause electric shock to users and damage equipment. Read instructions carefully. The charging device may become warm and may reach 50°C (122°F) under extended high power operation. During operation, keep the charging device away from materials that may be affected by these temperatures.

IMPORTANT SAFETY INSTRUCTIONS:

1. When used correctly, lithium-ion rechargeable batteries provide a safe and dependable source or portable power. However, if they are misused or abused, this may result in leakage, burns, fire or explosion/dissassembly, causing personal injury or damage to other devices.
2. Do not disassemble the charging device. There are no user-serviceable parts inside. Incorrect reassembly may result in shock or fire hazard.
3. Do not drop or subject the charging device to strong mechanical shock.
4. Do not expose the charging device to moisture, water, rain, snow or spray.
5. Do not insert any object into the ports or openings of the charging device.
6. Do not operate the charging device if it has received a sharp blow, been dropped, or otherwise been damaged in any way.
7. Do not use in environments where the temperature is 40°C (104°F) or greater.
8. Keep out of reach of children.
9. To reduce the risk of electric shock, unplug the charging device from any power source before attempting any maintenance or cleaning.

OPERATING INSTRUCTIONS

CHARGE BEFORE USE

Charging the Instant USB Charger:

1. Connect the mini USB end of the cable provided to the Instant USB Charger's IN port (Charging Indicator Light is located next to it).

2. Connect the USB end of the cable provided to your computer's USB port or another USB 2.0 compatible port.
3. The Instant USB Charger's charge indicator light turns red to indicate the battery is being charged. The charger can be charged when the switch is either on the ON or OFF position.

4. When the battery is fully charged, the charge indicator light, located at the end of the charger, turns green. Disconnect the charger from the USB cable. The charger is now ready to use.

Using the Instant USB Charger:

1. The Instant USB Charger must be fully charged before use (see "Charging the Instant USB Charger").
2. Connect a USB cable compatible with your device to the USB Power Port. A device-specific USB cable is not supplied. These are available from almost all electrical retailers. The cable supplied for connecting the USB to the mini USB is compatible with newer Motorola® mobile phones and BlackBerrys®. Please note most newer Motorola® mobile phones cannot be charged using conventional USB cables. For such devices, the mini USB cable supplied must be used.
3. Connect the other end of the USB cable to your device.
4. Turn the Instant USB Charger switch to the ON position.
5. The LED status light turns green, indicating that the Instant USB Charger is charging your device. The LED status light turns red when the charger is flat and needs to be recharged.
6. When the charger is not in use, the switch must be turned to the OFF position. This will prevent the charger from losing its charge.

Technical Data

Output voltage: 5 volts DC

Input voltage: 5 volts DC, max. 1 amp

CORRECT DISPOSAL FOR THIS CHARGING DEVICE

Please follow any local requirements to recycle this charging device for used electronic appliances and rechargeable batteries.

